


How to use The Meccano Magic Motor

Before winding the Motor, oil the bearings and gears with thin sewing machine oil. This oiling should be repeated at frequent intervals.

See that the brake lever 1 is pressed down. Then press the key on to the winding shaft 2 to its fullest extent and wind anti-clockwise only as indicated by the arrow on the side-plate. **Do not turn the Key Clockwise.**



To start the Motor release brake lever.

When the Motor is used to drive models the ~~extra Pulley~~ supplied with it should be secured to the driven Axle Rod by means of the grub screw. A Driving Band of suitable length is passed over this Pulley and round the Pulley 3, and then serves as a driving belt. Three pairs of Driving Bands of different length are supplied with the Motor.

If the above instructions are carried out the *Magic Motor* will give excellent service.

By driving your models with a Motor you

will add to the interest and get far more fun !

Meccano Limited

-

Binns Road

-

Liverpool 13