

Inhalt der Baukästen — MÄRKLIN —

Nr.	Bezeichnung der Teile	Stückzahl der in den Kästen befindlichen Einzelteile																Nr.	
		00	00A	0	0A	1	1A	2	2A	3	3A	4	4A	5	5AA	5AB	5A	6	
1	Flachband, 25 Loch, 32 cm	—	—	—	4	4	6	10	—	10	4	14	10	24	18	18	36	60	1
1 d	" 17 " 21,5 "	2	2	4	2	6	10	16	2	18	4	22	2	2	18	18	36	2	1 d
2	" 11 " 14 "	—	—	—	—	2	2	2	2	4	2	6	4	10	10	10	20	30	2
2 a	" 9 " 11 "	—	—	1	1	1	2	4	6	—	6	8	14	18	18	18	36	50	2 a
3	" 7 " 9 "	—	—	—	—	—	—	4	4	4	4	4	8	8	8	8	16	24	3
4	" 6 " 7,5 "	—	—	—	—	—	—	2	2	2	2	4	8	8	8	8	16	24	4
5	" 5 " 6 "	—	—	—	—	—	—	2	2	2	2	4	12	10	22	18	40	3	5
6	" 4 " 5 "	—	—	—	—	—	—	2	2	2	2	4	8	8	12	27	27	54	6
7	" 3 " 3,5 "	—	—	—	—	—	—	2	2	2	2	4	10	4	14	14	6	10	20
8	Winkelträger, 25 Loch, 32 cm	—	—	—	—	—	—	4	4	4	4	8	2	2	2	2	—	24	8 d
8 d	" 17 " 21,5 "	—	—	—	—	—	—	—	—	4	4	8	2	2	10	2	6	16	8 d
9	" 11 " 14 "	—	—	—	—	—	—	—	—	4	4	8	2	2	2	—	—	2	9
9 b	" 9 " 11 "	—	—	—	—	—	—	—	—	2	2	2	—	—	—	—	—	2	9 b
9 c	" 7 " 9 "	—	—	—	—	—	—	—	—	2	2	2	—	—	—	—	—	2	9 c
10	Flachstück	4	—	4	—	4	—	4	—	4	4	8	8	16	7	7	14	30	10
11	Führungsbügel	—	—	—	—	—	—	—	—	—	—	—	—	4	6	6	12	16	11
12	Winkelstück	8	—	8	4	12	—	12	12	24	12	36	36	72	66	66	132	204	12
13	Welle, 30 cm	—	—	—	—	—	—	—	—	—	2	2	2	4	1	1	2	6	13
13 a	" 20 "	—	—	—	—	—	—	—	—	—	—	1	1	1	1	1	2	4	13 a
14	" 15 "	—	—	—	—	—	—	—	—	—	2	2	2	4	1	1	2	6	14
15	" 13 "	—	—	—	—	—	—	—	—	3	3	1	4	5	3	8	4	15	15
15 a	" 11,5 "	—	—	—	—	—	—	2	1	3	2	2	—	3	1	4	2	8	15 a
16	" 9 "	—	—	—	—	—	—	2	2	2	2	2	4	2	6	1	2	8	16
17	" 5 "	—	—	—	—	—	—	2	2	2	2	4	4	—	4	2	2	4	8
18	" 3 "	—	—	—	—	—	—	2	2	2	2	4	4	—	4	2	2	4	8
19	Handkurbel, 17 cm	—	—	—	—	—	—	1	1	1	1	1	2	1	3	3	1	6	19
20	Spurkranzrad, 36 mm Durchmesser	—	—	—	—	—	—	—	4	4	4	4	8	8	—	—	—	8	20
21	Schnurlaufrad, 38 "	—	—	—	—	—	—	—	—	1	1	1	1	1	1	2	—	2	21
22 a	" 25 " ohne Büchse	4	—	4	2	6	—	6	—	6	—	6	—	6	3	9	—	1	22 a
22	" 25 " mit Klauenkopplung	4	—	4	2	6	—	6	—	6	—	6	—	6	1	1	1	10	22
22 K	" 25 " mit Klauenkopplung	—	—	—	—	—	—	—	—	—	2	2	2	4	6	—	—	6	22 K
23	Schnurlaufrolle, 12 mm Durchmesser	1	—	1	—	1	—	1	—	1	—	1	1	2	4	6	—	23	
24	Lochscheibenrad, 36 "	1	—	1	—	1	—	1	—	1	—	1	1	2	—	2	4	6	24
25	Zahnrad, 18 mm Durchm. 25 Zähne	—	—	—	—	—	—	—	—	—	1	1	1	2	—	—	—	2	25
25 K	" 18 " 25 mit Klauenkopplung	—	—	—	—	—	—	—	—	—	2	2	—	2	—	—	1	1	25 K
26	" 14 " 19 "	—	—	—	—	—	—	—	—	—	1	1	1	2	4	6	—	2	26
26 K	" 14 " 19 mit Klauenkopplung	—	—	—	—	—	—	—	—	—	1	1	1	2	4	6	—	2	26 K
27	" 35 " 50 "	—	—	—	—	—	—	—	—	—	1	1	1	2	—	2	2	27	27
28	Kronrad, 38 " 50 "	—	—	—	—	—	—	—	—	—	1	1	1	1	1	1	1	2	28
29	" 19 " 25 "	—	—	—	—	—	—	—	—	—	2	2	—	2	—	—	2	2	29
30	Kettenrad, 38 " 23 "	—	—	—	—	—	—	—	—	—	1	1	1	1	1	1	—	1	30
30 a	" 20 " 11 "	—	—	—	—	—	—	—	—	—	1	1	1	1	1	1	1	1	30 a
32	Schnecke, 14 "	—	—	—	—	—	—	—	—	—	1	1	1	1	1	1	1	1	32
33	Sperrklinke, groß	—	—	—	—	—	—	—	—	—	2	2	—	2	—	2	—	2	33
33 a	" klein	—	—	—	—	—	—	—	—	2	2	—	2	—	2	—	2	33 a	
34	Schraubenschlüssel	—	1	1	—	—	—	—	—	1	1	2	2	—	2	—	2	34	
35	Klemmmuffe	3	—	3	—	3	—	3	6	—	6	3	9	—	9	—	3	12	35
35 a	"	3	—	3	—	3	—	3	6	—	6	3	9	—	9	—	3	12	35 a
36	Schraubenzieher	—	1	—	1	—	1	—	1	—	1	1	—	1	—	1	—	1	36
36 H	mit Holzgriff	—	1	—	1	—	1	—	1	—	1	1	—	1	—	1	—	1	36 H
37 a-37ka	Schraube mit Holzgriff	25	10	35	5	40	40	80	45	125	50	175	75	250	225	175	400	650	37 a-37 ka
37 b	Mutter	25	10	35	5	40	40	80	45	125	50	175	75	250	225	175	400	650	37 b

Inhalt der Baukästen — MÄRKLIN — (Fortsetzung)

Nr.	Bezeichnung der Teile	Stückzahl der in den Kasten befindlichen Einzelteile																Nr.	
		00	00A	0	0A	1	1A	2	2A	3	3A	4	4A	5	5AA	5AB	5 A	6	
39	Antriebskette, 1 Meter lang	—	—	—	—	—	—	—	—	1	1	—	1	—	—	—	—	1	39
40	Transmissionsschnur, Bündel von 4 Meter	—	—	1	1	—	1	2	1	3	1	4	2	6	1	1	2	8	40
41 b	Propellerflügel	—	—	—	—	—	—	—	—	—	—	2	2	2	—	—	2	2	41 b
42	Kette, Bündel von 4 Meter	—	—	—	—	—	—	—	—	—	—	1	1	1	—	—	1	1	42
43	Spiralfeder	—	—	—	—	—	—	—	—	1	1	1	1	1	—	—	1	2	43
44	Lagergabel	—	—	1	—	1	—	1	—	1	1	1	2	2	1	1	2	2	44
45	Lagerbock	—	—	—	—	—	—	—	—	1	1	1	2	2	1	2	4	45	
46	Lagerbitgel	—	—	—	—	2	2	—	2	2	1	1	3	4	2	2	4	8	46
47	Doppelwinkel	—	—	—	—	—	—	—	—	—	2	6	4	10	5	5	10	20	47
51	Schieberöse	—	—	—	—	—	—	—	—	—	—	1	1	1	1	1	1	2	51
52	Rechteckplatte, 14×6 cm	1	—	1	—	1	—	1	1	2	—	2	2	4	2	2	4	8	52
53	8,5×6	—	—	—	—	—	—	—	—	3	3	1	4	6	5	5	10	16	53
54	Sektorplatte	—	—	1	1	1	2	—	2	—	2	1	3	3	—	1	1	4	54
55	Transmissionsspirale, 15 cm	—	—	—	—	1	1	—	1	—	1	1	2	4	2	2	4	8	55
55 a	45	—	—	—	—	—	—	—	—	—	2	2	2	1	1	—	1	2	55 a
56	Kurbelarm	—	—	—	—	—	—	—	—	—	—	—	2	2	2	—	2	2	56
57	Lasthaken	—	—	1	1	—	1	2	2	—	1	—	1	1	—	1	1	2	57
59	Stellring mit Schraube	—	—	—	—	—	—	1	—	—	—	—	10	14	24	20	20	40	64
60/7	Verbindungsbügel, 7 Loch	1	—	1	3	2	4	2	6	—	6	8	4	12	12	12	24	36	60/7
61	Windmühlenflügel	—	—	—	—	—	—	—	—	1	1	5	6	6	—	—	6	61	
63	Kupplungsmuffe mit 6 Stellschrauben	—	—	—	—	—	—	—	—	1	1	2	2	2	4	—	—	4	64
64	Schornstein	—	—	—	—	—	—	—	—	—	1	1	1	1	1	—	1	1	65
65	Schneckengehäuse	—	—	—	—	—	—	—	—	—	1	1	2	2	2	4	—	4	65 a
65 a	Lagerband	—	—	—	—	—	—	—	—	—	—	2	2	2	4	—	—	4	65 a
66	Runde Platte, 9,5 cm Durchmesser	—	—	—	—	—	—	—	—	2	2	1	3	4	2	2	4	8	66
67	6,5	—	—	—	—	2	2	2	4	—	4	—	4	4	2	2	4	8	67
68	Großer Ring, 19,5	—	—	—	—	—	—	—	—	—	—	—	—	—	1	1	2	2	68
69 a	Speichenrad, 7 mit Büchse	—	—	—	—	—	—	—	—	—	—	—	—	—	2	2	4	4	69 a
70	Anleitungsbuch für Kasten Nr. 00 und 0	1	—	1	—	1	1	—	1	—	1	—	1	—	—	—	—	70	70
71 a	" 1—3	—	—	—	—	1	1	—	1	—	1	—	1	—	1	—	1	1	71 a
71 b	" 4—6	—	—	—	—	—	—	—	—	—	1	1	1	1	1	1	1	1	71 b
72	Motoren	—	—	—	—	—	—	—	—	—	—	—	—	—	—	1	1	1	72
81/1	Geländerband, 25 Loch, 32 cm	—	—	—	—	—	—	—	—	—	—	—	—	10	10	5	5	10	20
81/2	11 14	—	—	—	—	—	—	—	—	—	—	—	6	6	2	2	4	10	81/2
81/5	5 6	—	—	—	—	—	—	—	—	—	—	—	6	6	2	2	4	10	81/5
87	Unterlagscheibe	—	—	—	—	—	—	10	10	—	10	6	16	4	20	10	24	4	87
88	Lagerstütze	—	—	—	—	—	—	—	—	2	2	2	2	2	—	—	4	88	
89/21	Zahnkranz, passend zu Nr. 21	—	—	—	—	—	—	—	—	2	2	—	2	2	2	—	2	2	89/21
89/22	" 22	—	—	—	—	1	1	—	1	1	2	—	2	2	—	—	2	2	89/22
89/66	" 66	—	—	—	—	1	1	—	1	1	1	—	1	1	1	1	1	1	89/66
89/67	" 67	—	—	—	—	1	1	—	1	1	1	2	—	2	—	—	2	2	89/67
89/68	" 68	—	—	—	—	—	—	—	—	—	—	—	—	1	1	2	2	2	89/68
108/15	Flachband, doppelreihig, 15 Loch, 19 cm	—	—	—	—	—	—	—	—	—	—	—	2	2	2	2	2	2	108/15
108/9	9 11	—	—	—	—	—	—	—	—	—	—	2	2	2	2	2	2	2	108/9
110	Bogenband, 6,5 cm	2	2	—	—	2	2	4	—	4	4	8	—	8	—	—	8	110	
111/7	Flachband, oval gelocht, 7 Loch, 9,5 cm	—	—	—	—	—	—	—	—	2	2	4	—	4	—	—	4	111/7	
111/5	5 6,5	—	—	—	—	—	—	—	—	2	2	4	—	4	—	—	4	111/5	
133	Wellenhalter	—	—	—	—	—	—	—	—	—	—	—	6	6	—	6	12	133	
153	Rechteckplatte, flach, 11,5×6 cm	—	—	—	—	—	—	—	—	—	—	2	2	2	—	2	2	153	
153 a	" 6×6	—	—	—	—	—	—	—	—	—	—	2	2	2	—	2	2	153 a	